

Mechanical Advantage

Mechanical advantage → $MA = \frac{F_o}{F_i}$

Output force (N)

Input force (N)

